

[Home](#) -- [Installation Kits](#) -- **Installation Kit Summary**

Installation Kits

See [Installation Kits](#) for large photos.

ECO INST-001

JIC #10 Inline Kit
Cummins and Detroit Engines

ECO INST-002

JIC #6 Inline Kit
Caterpillar Engines

ECO INST-003

Detroit and Mack Engines

ECO INST-004

5/16" or 3/8" Compression Assembly
For applications where metal fuel lines are cut and installation is done with 5/16" or 3/8" compression fittings.

ECO INST-005

3/8" Quick Disconnect Kit
For 3/8" Fuel Line on GMC, Chevrolets, 6.0 Powerstrokes, and Dodge Hemi's. Connection at Fuel Rails, Fuel Filters, or Fuel Pumps.

ECO INST-006

5/16" Quick Disconnect Kit
For 5/16" Fuel Line on Ford, Chryslers, Nissans, Toyotas, Fords, 7.3 Powerstrokes. Connection at Fuel Rails, Fuel Filters, or Fuel Pumps.

ECO INST-007

Gates Quick Disconnect Kit
For most Fords, Jaguars, Range Rovers, Volvos, Lincolns. Connection at Fuel Rails.

ECO INST-007-90

Gates Quick Disconnect Kit
For most Fords, Jaguars, Range Rovers, Volvos, Lincolns. Connection at Fuel Rails.

ECO INST-008

1/2" Quick Disconnect Kit
For 1/2" fuel line on Duramax and 6.4 Powerstrokes

ECO INST-009

For International Engines. DT466. Connection at Fuel Filter Outlet.

ECO INST-010

3/8" Flat Heat Cat

ECO INST-011

For Hyundai

ECO INST-012

For International Max Force 7

ECO INST-013

For Chevrolet and GM Installations with no quick disconnect. It installs on the outlet side of the fuel filter, underneath the vehicle, inside the chassis.

ECO INST-014

For International 365 - 444E

ECO INST-015

For Mercedes Diesel Trucks and Buses

ECO INST-016

For Dodge Diesel 5.9 Cummins